

# Easy Mounting Instructions

## Dart-Center ArrowPort™

**Required Tools:** Pencil, Drill, 5/32 or 3/16 inch Drill Bit\*, Hammer, phillips-head Screwdriver

**Suggested Tool:** Carpenter's or Spirit Level

### Mounting Steps

- 1.** Choose a mounting location for your ArrowPort. See Note "1" below. Make two marks on the wall, one 3/4 inch below the top of the ArrowPort and a second mark 8-11/16 inches below the first mark. For best appearance, use a level to plumb these two marks.
- 2.** Next, for drywall\*, drill one 5/32 inch hole in the center of each mark made in the previous step. Lightly hammer one plastic wall anchor (included) into each hole until the round flat top of the anchor is flush against the face of the wall. Note: the included wall anchors are suitable for drywall, concrete, plaster and masonry walls. For wood walls, omit this step; plastic anchors are not required. Simply drive the provided screws directly into the wood wall.
- 3.** Insert a screw (1 of 2 included) through the top mounting hole. Fasten the ArrowPort to the wall by aligning the top screw with the top plastic wall anchor. Drive in the top screw until the ArrowPort is tight against the wall. Use a level to check for plumb then drive in the lower screw. Be careful not to overtighten the screws. You're done!

\* Harder materials such as concrete, plaster, masonry, etc . . . require 3/16" pilot holes.

### Notes/ Cautions

- 1.** Locate your ArrowPort far enough from the dartboard so as to avoid stray darts.
- 2.** Caution! The metal edges may be sharp.
- 3.** Verify your ArrowPort is securely mounted to the wall prior to use. Check again periodically and re-mount as necessary to maintain secure wall mounting.
- 4.** Cleaning recommendation-- glass cleaner and a soft cloth.

Questions? Call Toll-Free (877) 271-STOP [7867]

